



PRE-RINSE UNIT INSTALLATION:

- 1) fix the tube (1) into the body (2) and fix it with a spanner
- 2) fix the swivel nozzle (9) into the metal tube (1) and tighten it with a spanner
- 3) install the spray gun bracket (15) into the metal tube (1) in order to fix the shower and pre-screw the knobs (16)
- 4) fix the rosone (4) into the bar (3) and fix it (5) (pic. 1)
- 5) put the bar (3) into the tube (1) in order to fix it on the wall and pre-screw the knobs (6)
- 6) install the tongs place (7) into the tube (1) and fix it (8) at a distance of 220mm ca. (pic. 2)
- 7) fix the bar for the wall fixing (3) into the tube (1) throw the narrowing of the knobs (6) at the needed distance (pic. 2)
- 8) fix the gasket (10) and the flexible (11) into the tube (1)
- 9) insert the spring (12) (pic. 3) in order to put it in its place (7) (pic. 4)
- 10) fix the gasket (3) and the shower (14) to the other end of the flexible hose (11)
- 11) fix the bracket (15) into the tube (1) throw the narrowing of the knobs (16) at a distance that allow you to fix the shower
- 12) make sure that all components have been fixed in order to avoid leaks

GY6
ggmgastro



GGM Gastro International GmbH
Weinerpark 16
D-48607 Ochtrup

www.ggmgastro.com info@ggmgastro.com
+49 2553 7220 0