



PRE-RINSE UNIT INSTALLATION:

- 1) fix the tube (3) into the body (9) and fix it with a spanner
- 2) fix the roson (12) into the bar (1) and fix it (13) (pic. 1)
- 3) put the bar (3) into the tube (1) in order to fix it on the wall and pre-screw the knobs (10)
- 4) install the tongs place (2) into the tube (3) and fix it (11) at a distance of 160mm ca. (pic. 2)
- 5) fix the bar for the wall fixing (1) into the tube (3) throw the narrowing of the knobs (10)
- 6) fix the gasket (5) and the flexible (4) into the tube (3)
- 7) insert the spring (6) (pic. 3) in order to put it in its place (2) (pic. 4)
- 8) fix the gasket (7) and the shower (8) to the other end of the flexible hose (4)
- 9) make sure that all components have been fixed in order to avoid leaks

GY7
ggmgastro



GGM Gastro International GmbH
Weinerpark 16
D-48607 Ochtrup

www.ggmgastro.com info@ggmgastro.com
+49 2553 7220 0