



PRE-RINSE INSTALLATION:

- 1) Take the main tap (1) and the swiveling nozzle (2) and connect the swiveling nozzle to the upper side of the main tap with the ring nut.
- 2) Insert the assembled tap (1-2) onto the sink leaving the OR gasket in place. Make sure the hole in the sink is 35mm.
- 3) Fix the assembled tap (1-2) by placing first the rubber washer and then the SS washer(5). Tighten the ring nut (6)with the tool (9) included.
- 4) Screw on the flexible hoses (7-8) to the down side of the tap and make sure it is fastened tightly.
- 5) Screw on the left and right nozzle(3-4) to the exterior parts of the assembled tap (1-2) and tighten with a spanner.
- 6) Make sure all components have been tightened properly.
- 7) Connect the armature to the water network.

BAY400
ggmgastro



GGM Gastro International GmbH
Weinerpark 16
D-48607 Ochtrup

www.ggmgastro.com info@ggmgastro.com
+49 2553 7220 0