



**PRE-RINSE UNIT INSTALLATION:**

- 1) take off the assembled tap (1) from the box
- 2) fix the swivel nozzle (16) into the body tap (1) and fix it with a spanner
- 3) remove chrome plate (20) from its place (pic. 5), fixing the clinical lever (17) to the cartridge and fix it with a screw (19), put the chromed plate (20) into the side of the clinical lever (pic. 6)
- 4) screw off the hexagon nut M30x1,5 (21) and take off the undulated spring washer (22) to fix it on the sink
- 5) insert the assembled tap (1) into the hole ø30,5 made on the sink, leaving the OR gasket (23) in its place into the body tap
- 6) fix the tap into the sink, inserting first the undulated spring washer (22) and fixing with the hexagon nut M30x1,5 (21)
- 7) fix the tube (2) into the body (1) and fix it with a spanner
- 8) install the spray gun bracket (15) into the metal tube (2) in order to fix the shower and pre-screw the knobs (9)
- 9) fix the rosons (4) into the bar (3) and fix it (5) (pic. 1)
- 10) put the bar (3) into the tube (2) in order to fix on the wall and pre-screw the knobs (6)
- 11) install the tongs place (7) into the tube (2) and fix it (8) at a distance of 220mm ca. (pic. 2)
- 12) fix the bar for the wall fixing (3) into the tube (2) throw the narrowing of the knobs (6) at the needed distance (pic. 2)
- 13) fix the gasket (10) and the flexible (11) into the tube (2)
- 14) insert the spring (12) (pic. 3) in order to put it in its place (7) (pic. 4)
- 15) fix the gasket (13) and the shower (14) to the other end of the flexible hose (11)
- 16) fix the bracket (15) into the tube (2) throw the narrowing of the knobs (9) at a distance that allow you to fix the shower
- 17) make sure that all components have been fixed in order to avoid leaks

**GY3**  
**ggmgastro**