



PRE-RINSE INSTALLATION:

- 1) take off the assembled tap (1) from the box
- 2) fix the swivel nozzle (7) into the body tap (1) and fix it with a spanner
- 3) remove chrome plate (10) from its place (pic. 1), fixing the clinical lever (6) to the cartridge and fix it with a screw (9), put the chromed plate (10) into the side of the clinical lever (pic. 2)
- 4) screw off the hexagon nut M30x1,5 (2) and take off the undulated spring washer (3) to fix it on the sink
- 5) insert the assembled tap (1) into the hole $\varnothing 30,5$ made on the sink, leaving the OR gasket (5) in its place into the body tap
- 6) fix the tap into the sink, inserting first the undulated spring washer (3) and fixing with the hexagon nut M30x1,5 (2)
- 7) screw the flexibles (4) to the body tap (1) and connect them to the waternetwork
- 8) make sure that all components have been fixed in order to avoid leaks

MY3
ggmgastro



GGM Gastro International GmbH
Weinerpark 16
D-48607 Ochtrup

www.gmgastro.com info@gmgastro.com
+49 2553 7220 0