



SPARE PARTS LIST FOR PRMTH5

CODE	NAME	SPECIFICATION	QTY
1	top cover	B5LA-01-01-01	1
2	connection frame	B5LA-01-02	1
3	bar	B5LA-01-03	1
4	bar spring	B5LA-03-06	1
5	bar pin	B5LA-03-05	1
6	Hexangular socket flat end set screw	M8x10	2
7	hex nut	M8	1
8	spring washer	8	1
9	flat washer	8	1
10	stop screw	B5LA-03-07	1
11	shock pad	B5LA-01-05-03	2
12	Electromagnetic switch base	B5LA-01-05-01	1
13	power cord lock nut	M16x1.5	1
14	potentiometer		1
15	electromagnetic switch		1
16	Circuit board shield	B7LB-03-12	1
17	hex nut	M5	2
18	flat washer	5	2
19	cross recessed countersunk head screw	M5x12	2
20	Circuit board	B7LB-03-11-01	1
21	Circuit board mounting board	B7LB-03-10	1
22	hex nut	M5	2
23	base	B5LA-01-07	1
24	flat washer	5	2
25	cross recessed countersunk head screw	M5x16	2
26	rubber feet	B5L-01-20	4
27	hexagon socket cap screws	M5x20	4
28	flat washer	5	2
29	spring washer	5	2
30	hexagon socket cap screws	M5x16	2
31	hexagon socket cap screws	M6x30	2
32	cross recessed countersunk head screw	M6x40	1

CODE	NAME	SPECIFICATION	QTY
33	Lock handle welder	B5LA-03-01-00	1
34	limit bending plate	B5LA-03-02	1
35	limit spring	B5LA-03-03	1
36	limit spring seat	B5LA-03-04-00	1
37	hexagon socket cap screws	M5x16	1
38	cross recessed countersunk head screw	M5x12	2
39	travel switch seat	B5LA-03-08	1
40	hex nut	M3	2
41	spring washer	3	2
42	flat washer	3	2
43	hex nut	M3	2
44	mircoswitch	RV-162-1C25	1
45	flat washer	3	2
46	cross recess pan head screw	M3x20	2
47	internal gear	B5LA-02-16	1
48	hexagon socket cap screws	M5x12	3
49	collecting ring	B5LA-02-17	1
50	protective cover	B5LA-01-13	1
51	flat washer	5	2
52	cross recess pan head screw	M5x20	1
53	bowl	B5LA-01-09	1
54	bowl pat	B5LA-01-08	1
55	motor	B5LA-02-01	1
56	motor gasket	B5LA-02-02	4
57	large gasket	5	4
58	spring washer	5	4
59	hexagon socket cap screws	M5x20	4
60	flat key	A3x10	1
61	small pulley	B5LA-02-03	1
62	ring	B5LA-02-03-01	1
63	circlip for shaft	8	1
64	synchronous belt	120XL-037	1

CODE	NAME	SPECIFICATION	QTY
65	hex nut	M8	1
66	flat washer	8	1
67	big belt wheel	B5LA-02-04	1
68	circlip for hole	26	1
69	bearing	6000	1
70	delf-seal packing	12x26x7	1
71	input shaft	B5LA-02-05	1
72	flat key	A3x10	1
73	flat key	A3x10	1
74	input shaft gear	B5LA-02-06	1
75	Input shaft sleeve	10	1
76	bearing	608	1
77	circlip for hole	22	1
78	bearing	608	1
79	bridge axis	B5LA-02-07	1
80	flat key	A3x10	1
81	bridge shaft gear	B5LA-02-08	1
82	circlip for shaft	10	1
83	bearing	608	1
84	hexagon socket cap screws	M5x16	7
85	spring washer	5	7
86	flat washer	5	7
87	box cover	B5LA-01-04	1
88	Countersunk decorative cover	B7LB-01-17	2
89	bearing	608	1
90	circlip for shaft	12	1
91	output shaft gear	B5LA-02-10	1
92	output shaft	B5LA-02-09	1
93	flat key	A3x10	1
94	flat key	A3x16	1
95	bearing	6001	1
96	delf-seal packing	12x25x7	1

CODE	NAME	SPECIFICATION	QTY
97	swivel base	B5LA-02-11	1
98	flat washer	8	1
99	cap nut	M8	1
100	circlip for shaft	10	1
101	planetary gear	B5LA-02-13	1
102	planetary gear washer	B5LA-02-14	1
103	bearing	61901	1
104	bearing	61901	1
105	delf-seal packing	20x25x7	1
106	flat key	A3x12	1
107	planetary shaft	B5LA-02-12	1
108	tap spring	B5LA-02-15	1
109	ball connecting shaft	B5LA-01-10-02	1
110	hexagon thin nut	M12	1
111	spring washer	12	1
112	flat washer	12	1
113	whisk	B5LA-01-10-00	1
114	ball seat cover	B5L-01-12-02	1
115	spring washer	6	1
116	hexagon socket cap screws	M6x16	1
117			
118			
119			
120			
121			
122			
123			
124			
125			
126			
127			
128			