




EPLSOSI e LISTE RICAMBI / *EXPLODED VIEW and SPARE PARTS LIST*






Detail 3



Detail A



Detail B

P07EN13007-PDP66BTC

Pos.	Code	Description
1	S40FN55037	ENTRY LH SIDE PANEL 8-12L MAX
2	S40FN55029	ENTRY RH SIDE PANEL 8-12L MAX
3	S35FN55045	ENTRY COMPLETE DOOR 6L÷9÷12L÷18 MAX
03.01	S66PT55019	ENTRY DOOR ASSEMBLY 6L÷9÷12L÷18 MAX
03.02	S66CG55013	COUNTERDOOR ASSEMBLY 6L÷9÷12L÷18 MAX
03.03	A90MI65003	ELESA HANDLE I 280/115 M12
03.04	A00PT59001	ENTRY GLASS CERAMIC PLATE 4-6-8-12
03.06	A86ME30004	ENTRY OVEN DOOR SPRING 6L÷9÷12L÷18
4	A95OO65008	REFRACTORY STONE 350X700X14
5	A87RZ65010	HEATING ELEMENT 900 W 230 V
6	A87RZ65007	HEATING ELEMENT 750 W 230 V
7	A90MP65001	SPHERIC KNOB PLX.30-M8-C9
8	A88SO86002	PROBE 600° C
9	A87IL73009	COMPLETE LAMP HOLDER 12V 20W G4 450°C
10	A86EL48001	EQUIPOTENTIAL CONNECTION
11	A86EL46004	CABLE GLAND OBO 106 PG 21
12	A86EL47003	NUT FOR CABLE GLAND OBO 106 PG 11
13	A88SE13001	POWER CARD TOUCH
14	A87IL72012	TRANSFORMER 40VA 50/60HZ 230V÷12V
15	A88SE81002	RELAY BOARD
17	A87CX62006	MAMMUT ASSEMBLY
18	A88SE13002	DISPLAY TOUCH
19	A87AZ69004	FOUR-POLE SWITCH 16A
20	A93OL65101	LABEL SWITCH
21	A87AZ69028	KNOB SWITCH
22	A94GU65010	DOOR SEAL 6L-9-12L-18

P07EN13008- PDP99TC

Pos.	Code	Description
1	S40FN55033	ENTRY LH SIDE PANEL 12-18 MAX
2	S40FN55025	ENTRY RH SIDE PANEL 12-18 MAX
3	S35FN55045	ENTRY COMPLETE DOOR 6L÷9÷12L÷18 MAX
03.01	S66PT55019	ENTRY DOOR ASSEMBLY 6L÷9÷12L÷18 MAX
03.02	S66CG55013	COUNTERDOOR ASSEMBLY 6L÷9÷12L÷18 MAX
03.03	A90MI65003	ELESA HANDLE I 280/115 M12
03.04	A00PT59001	ENTRY GLASS CERAMIC PLATE 4-6-8-12
03.06	A86ME30004	ENTRY OVEN DOOR SPRING 6L÷9÷12L÷18
4	A95OO65009	REFRACTORY STONE 350X1050X14
5	A87RZ65008	HEATING ELEMENT 1250 W 230 V
6	A87RZ65010	HEATING ELEMENT 900 W 230 V
7	A90MP65001	SPHERIC KNOB PLX.30-M8-C9
8	A88SO86002	PROBE 600° C
9	A87IL73009	COMPLETE LAMP HOLDER 12V 20W G4 450°C
10	A86EL48001	EQUIPOTENTIAL CONNECTION
11	A86EL46004	CABLE GLAND OBO 106 PG 21
12	A86EL47003	NUT FOR CABLE GLAND OBO 106 PG 11
13	A88SE13001	POWER CARD TOUCH
14	A87IL72012	TRANSFORMER 40VA 50/60HZ 230V÷12V
15	A88SE81002	RELAY BOARD
17	A87CX62006	MAMMUT ASSEMBLY
18	A88SE13002	DISPLAY TOUCH
19	A87AZ69004	FOUR-POLE SWITCH 16A
20	A93OL65101	LABEL SWITCH
21	A87AZ69028	KNOB SWITCH
22	A94GU65010	DOOR SEAL 6L-9-12L-18