

The yellow parts are the mostly replacement parts

Diagram	Part #	Description
	1	Front Ring Nut
	2	4.5mm Grinder Plate
	3	10mm Grinder Plate
	4	Grinder Knife
	5	Auger
	6	Auger Sleeve
	7	Grinder Head
	8	Meat Tray
	9	Meat Stomper
	10	Locking Knob
	11	Housing
	12	Reverse Switch
	13	Fuse Protection
	14	ON/OFF Switch