


The yellow parts are the mostly replacement parts

Diagram	Part #	Description
 <p>The diagram shows an exploded view of a meat grinder. The main housing is a rectangular box with a front panel. A meat tray is shown inside the top. A grinder head is attached to the front. A switch and a locking screw are also shown. Labels with arrows point to: Meat Tray, Housing, Switch, Grinder Head, and Locking Screw.</p>	1	Front Ring Nut
	2	4.5mm Grinder Plate
	3	Grinder Knife
	4	Grinder Auger
	5	Auger Sleeve
	6	Grinder Head
	7	Housing
	8	Locking Knob
	9	ON/OFF Switch
	10	Reverse Switch
	11	Meat Stomper
	12	8mm Grinder Plate