USER MANUAL

Eggs & Knives Sterilizer









ATTENTION! Before using the device for the first time, read the operating instructions carefully. The manual should be kept in a safe and accessible place for personnel. The manufacturer reserves the right to change the technical parameters of the devices without prior notice. Photos, drawings and descriptions of devices are for illustration only.

I. SAFETY REGULATIONS

- Incorrect operation and improper use may seriously damage the device or damage your health.
- The device may only be used for the purpose for which it has been designed.
- The manufacturer is not liable for any damage caused by improper handling and improper use of the device.
- When in use, protect the device and its power cord plug from contact with water or other liquids.
- In the event that the device accidentally falls into water, immediately pull the plug out of the socket and have the device checked by a specialist. Failure to follow these instructions can be life-threatening.
- Never open the casing of the device yourself.
- Do not stick any objects into the housing of the device.
- Do not touch the plug of the power cord with wet hands.
- Regularly check the condition of the plug and cable. In the event of detection of damage to the plug or cable, have it repaired at a specialized repair point.
- In the event that the device is dropped or damaged in any other way, always have it checked and repaired at a specialized repair shop before further use.
- Never repair the device yourself it may be life-threatening.
- Protect the power cord from contact with sharp or hot objects and keep it away from open flames.
- When you want to disconnect the device from the socket, always grasp the plug, never pull the cord.
- Secure the cord (or extension cord) so that no one accidentally pulls it out of the socket or stumbles over it.
- The device is designed for surface disinfection of objects, especially eggs. The exposure time is 2.5 minutes, which allows the destruction of up to 100% of Salmonella, Coli and cocci).
- Control the functioning of the device while in use.
- Children are not aware of the dangers that can be caused by the use of electrical appliances. Never let children use electrical household appliances unsupervised.
- If the device is not currently in use or is being cleaned, always disconnect it from the power source by removing the plug from the socket.
- Switch off the device before removing the plug from the socket.

2. WARNINGS

- Do not use any measures other than those provided with the device.
- Never place the device near any heat sources (eg a stove or stove).
- High voltage! Disconnect the device from the power supply before repair or cleaning.
- Keep away from flammable objects.
- Check local voltage before startup.
- In the event of damage, the power cord must be repaired or replaced by a specialist at the repair service.




ATTENTION! If the power cord plug is connected to the socket, the device remains live all the time.

3. BUILDING

The device is made of high-class stainless steel, thanks to which it is resistant to discoloration and cracking of the housing. Four durable lamps are used in the UV sterilizer. The sterilizer is equipped with a special contactor preventing the device from being turned on when the drawer is open.



ATTENTION! Do not force the lamps to light when the drawer is open, UV is harmful to health.



4. SERVICE

Remember to clean the eggs from feather dust and other dirt beforehand.

Follow the instructions below to decontaminate your eggs:

- · Open the floodlight drawer
- · Remove the grille
- Place the rack with the handles facing down on the eggs (located on the drawpiece)
- Take the grille with the drawpiece and turn it 180°
- Remove the drawpiece
- Place the egg rack in the drawer and close it.

The lighting of the LEDs: Front up and down lamps and Back up and down lamps signals the operation of the device.

The diodes going off informs about the end of the device operation. The process time is approximately 2.5 minutes.

5. CLEANING

- Always remove the plug from the socket before cleaning!
- Clean the device with a dry brush or brush.
- Make sure that the electrical components of the device do not come into contact with water.

6. TECHNICAL DATA

Model	Eggs & Knives Sterilizer
Voltage	220-230 V
Frequency	50-60Hz
Total power	50 W
UV lamp power	16 W
Capacity	30 eggs
Exposure time	150 knot.
Weight	9.8 kg
Dimensions	
Width	471 mm
Length	360 mm
Height	226 mm

7. DISPOSAL OF USED DEVICES

After the end of the equipment's useful life or when you buy a new one, you can return the old device to us. Send it to us and a specialized company will dispose of it in accordance with the Act on waste electrical and electronic equipment (Journal of Laws 2005 No. 180 item 1495)

8. WARRANTY

The seller is liable under the warranty or guarantee.

In the event of damage resulting from the formation of calcium deposits in the device, they are not subject to warranty repair.

Warranty replacement does not apply to such elements as: bulbs, rubber elements, heating elements damaged by limescale, screws and elements subject to natural wear, e.g. burners, rubber seals and all kinds of mechanically damaged elements.

9. NAME PLATE

