



NO.	SPARE PART NAME	QUANTITY
1	Posterior shell	1
2	Heater fan switch	1
3	Motor switch	1
4	Temperature controller	1
5	bolt	1
6	Oil guide square pipe	1
7	heater	1
8	Decorative cover	1
9	Safety net	1
10	hopper	1
11	screw	1
12	Squeeze gun	1
13	Anti-scalding cover under heater	1
14	Anti-scalding cover on heater	1
15	Probe fixed square bar	1
16	Heater baffle	2
17	Flat bearing	1
18	motor	1
19	capacitance	1
20	fan	1
21	Bottom plate	1
22	Machine foot	4
23	Overload protector	1