



PART NO.	Material Code	DESCRIPTION
1	2. HB350003202100	grinding cover
2	2. HB350023302100	blade protection plate
3	3. HBS3000095070100	knob
4	2. DPDD360502801100	blade
5	2. HB350-0241120190	spindle of blade
6	2. HB35002321021	plate
7	4. 01. 6207GBT294166	bearing
8	2. 0000065	sharpner component
9	2. HB350003102100	stand of sharpner
10	2. HB3500131B02100	locating plate
11	2. HB350023102100	knife holder
12	2. HB350004907200	scraping board
13	2. HB350014207100	protection block
14	4. 01. 6206 2RS GBT294166	bearing
15	2. HB350-0245120140	isolating sleeve
16	4. 01. 05GBT 117110510001	V-belt
17	2. HB350-1007220200	belt wheel
18	2. HB3500563-1511501	Handle
19	2. HB3500562-1511501	Handle seat
20	2. HB3500564-1511501	bushing
21	2. HB3500511A01100	Push rod bracket
22	2. HB3500565-9011501	connecting rod

23	2. HB3500542A01100	Push rod
24	2. HB350054601200	pressing plate
25	2. HB3500561-15101901	Push rod bracket
26	2. HB350054301200	Push rod bracket cover
27	2. HB350053102100	carriage
28	2. HB350051201200	pressor
29	2. HB320-0544120340	hanblebar
30	2. HB350-0541120340	slide bar
31	4. 02. 00000043	spring
32	2. HB4000000000001	sliding block
33	2. HB4000000000001	sliding block
34	2. HB4000000000001	sliding block
35		rail bracket
36	2. HB350064907100	cover plate
37	2. HB350061201200	slide seat
38	2. HB350120100	guide
39	2. HB350-0645120140	pin
40	2. HB350-0646120140	roller
41	2. HB3500644120140	pin
42	2. HB350061101100	crank
43	2. HB3500642120200	gear
44	2. HB350063102100	body
45	2. HB350065007100	cover plate
46	4. 02. 00000012	copper bush
47	2. HB350-0651110300	Copper Gasket
48	4. 02. 00000044	spring
49	2. HB350064100000	worm
50	2. HB350-0632110300	bushing
51	2. HB3800304-90901	plastic handle
52	2. HB35004141-512001	baseboard
53	2. HB35004142-511601	baseboard
54	2. HB35004143-512001	sliding plate
55	2. HB350-044301100	screw
56	2. HB350044401100	Bracket
57	2. HB350004507100	Rear panel
58	2. HB400100501100	Bearing cover I
59	2. HB40002460000	belt wheel seat
60	2. HB400100601100	Bearing cover II
61	2. HB400-1004120100	Stepped belt wheel shaft
62	2. HB4001003-511901	Stepped belt wheel
63	4. 01. 05GBT11 7110813001	V-belt
64	4. 01. M16230 GBT897036	Joint bearing connecting rod
65	2. HB350041101100	big crank
66	2. HB350004607100	Left panel
67	1. 04. JSJ3500001	Reducer
68	2. HB350004307100	Right side corner panel
69	2. HB350-0413220250	wheel of reducer
70	4. 01. 05GBT11 7110813001	V-belt
71	1. 04. BSQHB35000001	Transmission
72	1. 04. 11001308100	motor
73	2. HB35004411	Iron panel
74	2. HB350004407100	front panel
75	2. HB350004207100	Left side corner panel 2
76	4. 02. 00000069	Directional wheel
77	2. HB4000441010	Frame welding

78	4. 02. 00000070	Universal wheel
79	2. HB350-044301100	bolt
80	2. HB400200201100	plate
81	3. HJ2240070100	Tighten handle
82	2. HB350004107100	Left side corner plate 1
83	2. HB350004707100	Right panel
84	1. 05. 015111HB320	Switch
85	1. 05. 015211HB320LAY16	Switch
86	1. 03. 00020001	indicator light
87	1. 05. 025011HB320LW2620C	Transfer switch
88	2. HB350093102100	Button Box
89	2. HB350013202100	Slide bracket
90	2. HB3500443201100	bolt
91	2. HB350053402100	Pedestal
92	2. HB350054701100	baffle
93	2. HB3500531302100	hook