



SPARE PARTS LIST OF AGG-ND

NO.	CODE	Name	Q 'ty	Unit	
1	/	foamed body	1	set	
2	JT-900-0032	glass clamp	6	set	
3	/	Glass+rubber parts	2	set	
4	JT-380-0021	glass corner	6	pcs	
5	/	top glass	1	pcs	
6	/	back glass	1	pcs	
7	JT-380-0018	fixing nut	6	pcs	
8	JT-380-0019	Fixing bolts	6	pcs	
9	JT-380-0020	Rubber sleeve	6	pcs	
10	JT-330-0012	cover	1	pcs	
11	JT-330-0013	Line Card	2	pcs	
12	JT-380-0015	power cord	1	pcs	
13	JT-330-0014	End socket	1	pcs	
14	JT-330-0015	engine base plate	1	pcs	
15	JT-330-0016	compressor	1	pcs	
16	JT-330-0017	Fan fixing plate	1	pcs	
17	JT380-0004	condensor fan	1	pcs	
18	JT-450-0011	temperature sensor	1	pcs	
19	JT-330-0018	engine plate	1	pcs	
20	JT-380-0014	condensor	1	pcs	
21	JT-450-0027	digital controller	1	pcs	
22	JT-450-0026	main switch	1	pcs	
23	JT-330-0019	pan divider	1	set	