



NO.	Coding	Description
1	ELE404030045	Gray knob
2	ELE404060041	Plastic indicator Green
3	ELE404030044	Gray knob 0°C Proportional
4	ELE404080089	Governor
5	ELE404030067	Gray knob 1-3 gears
6	ELE404080079	Three gear switch
7	E-DTT-450-20	Slag tray handle
8	E-DTT-450-04	Side panel
9	E-DTT-450-29	Front lower plate
10	ELE404070006	Fan
11	HAR403060018	Feet
12	E-DTT-450-28	Fan cover
13	E-DTT-450-27	Bottom plate
14	E-DTT-450-17	Control box
15	E-DTT-450-19	Slag tray
16	HAR403150163	Net
17	E-DTT-450-03	Side support
18	E-DTT-450-09	Heating mounting plate
19	ELE404070005	Motor
20	HAR403110011	Motor gear
21	E-DTT-450-16	Left and right side panels
22	E-DTT-450-01	Right sealing plate
23	HAR403110066	Chain
24	HAR403110025	Sprocket gear
25	E-DTT-450-10	Net pole mounting plate
26	E-DTT-450-26	Back plate
27	E-DTT-450-30	Back plate handle
28	E-DTT-450-18	Back cover
29	E-DTT-450-25	Back plate
30	ELE404130171	Power cable
31	ELE404130005	Outlet sheath
32	E-DTT-450-23	Top cover
33	E-DTT-450-24	Top cover support
34	E-DTT-450-21	Cover
35	E-DTT-450-22	Rear insulation board
36	E-DTT-450-13	Upper heater cover
37	E-DTT-450-06	Lower heater cover
38	ELE404010171	Upper heater
39	ELE404010172	Lower heater
40	HAR403010284	Chain net pole
41	E-DTT-450-07	Heater left support
42	E-DTT-450-15	Upper beam
43	E-DTT-450-02	Left sealing plate
44	E-DTT-450-16	Left and right side panels
45	ELE404040022	Terminal
46	HAR403150162	Grid
47	E-DTT-450-04	Side panel