



| No. | Code | Description |
|-----|--------------|----------------------------|
| 1 | E-DZ-12L-01 | Countertop |
| 2 | ELE404010004 | Heater |
| 3 | E-DZ-12L-12 | Fixed part of probe |
| 4 | E-DZ-12L-07 | Heater guard plate |
| 5 | HAR403010068 | Fixed pin |
| 6 | E-DZ-12L-11 | Fryer basket hanging board |
| 7 | E-DZ-12L-04 | Control panel |
| 8 | E-DZ-12L-05 | Back panel of control box |
| 9 | ELE404130005 | Water joint |
| 10 | ELE404080140 | Thermostat |
| 11 | ELE404080047 | Hi-limit |
| 12 | ELE404080099 | Micro switch |
| 13 | ELE404020010 | Switch |
| 14 | ELE404060041 | Instruction light (Green) |
| 15 | ELE404030045 | Knob |
| 16 | ELE404060038 | Instruction light (Yellow) |
| 17 | HAR403170083 | Handle of lip |
| 18 | E-DZ-12L-10 | Oil tank lip |
| 19 | HAR403150003 | Fryer basket |
| 20 | E-DZ-12L-09 | Cover panel of heater |
| 21 | E-DZ-12L-03 | Front panel |
| 22 | ELE404110074 | Drain valve |
| 23 | HAR403180133 | Drain valve joint |
| 24 | HAR403060046 | Foot |
| 25 | E-DZ-12L-08 | Foot plate |
| 26 | E-DZ-12L-02 | Side panel |