



Position of item	Code	Nr. of pieces	Description
1	35037500	4	HEATING PLATE 300X300 3kW 400V
2	22049900	4	ELECTRIC PLATE SWITCH
3	25186100	8	GREY TERMINAL 10 mm ²
4	25186500	1	GROUND TERMINAL 10 mm ²
5	25186700	1	STOP TERMINAL
6	30169500	1	GREEN BULB 400V (415/440V)Ø13mm T150°
7	30169300	1	GREEN LIGHT LENS Ø13mm
8	38952000	4	KNOB BACKING FOR ELECTRIC PLATES
9	38877500	6	KNOB PA66 PIN 6x4.6 SPACER - Models from 04/2010
10	24685100	4	FOOT 2 - h125/175 - Models from 1/2014
11	30169000	1	ORANGE BULB 230V Ø13mm T150°
12	30169200	1	ORANGE LIGHT LENS Ø13mm
13	30064900	1	THREE-PHASE WORKING THERMOSTAT (270° C)
14	22049800	1	4 POSITION SWITCH
15	35301400	1	THREE-PHASE SAFETY THERMOSTAT (360° C)
16	31320400	3	BOTTOM ELEMENT 1.5 kW 230V FE 7/900-K-
17	31320000	3	TOP ELEMENT 0.99 kW 230V FE 7/900-K-
18	31842000	1	OVEN CHAMBER BOTTOM 650 x 535 mm
19	31802500	2	OVEN HINGE ROLLER HOLDER - Models from 9/2008
20	31802000	1	OVEN DOOR LEFT HINGE - Models from 1/2000
21	31802100	1	OVEN DOOR RIGHT HINGE - Models from 1/2000
22	35857900	2	MATT FLUE PROTECTION GRILL, 400 mm
23	38952300	1	KNOB BACKING 50°C - 270°C
24	38952400	1	KNOB BACKING FOR 2/1 GN ELECTRIC OVENS