




Position of item	Code	Nr. of pieces	Description
1	38908300	1	PLATE uncabled
2	35927800	4	ELEMENT 3500W - 380V FOR E9TP
3	30065400	4	THREE-PHASE WORKING THERMOSTAT (400° C)
4	22050300	5	FOUR-POLE FASTON SWITCH
5	30064900	1	THREE-PHASE WORKING THERMOSTAT (270° C)
6	35301400	1	SAFETY THERMOSTAT 360°
7	38952825	4	PA66 SATIN BACKPLATE
8	27112300	5	KNOB FOR ELECTRICAL EQUIPMENT
9	27112100	5	KNOB COVER FOR GAS/ELECTRICAL EQUIPMENT
10	38952315	1	SATIN BACKPLATE FOR ELECTRIC OVENS
11	30169100	1	GREEN BULB 230V Ø13mm T150°
12	30169000	1	ORANGE BULB 230V Ø13mm T150°
13	30169300	1	GREEN LIGHT LENS Ø13mm
14	30169200	1	ORANGE LIGHT LENS Ø13mm
15	30169600	2	FIXING CROWN Ø13 FOR INDICATOR LIGHTS
16	31802000	1	OVEN DOOR LEFT HINGE - Models from 1/2000
17	31802100	1	OVEN DOOR RIGHT HINGE - Models from 1/2000
18	31802500	2	OVEN HINGE ROLLER HOLDER - Models from 9/2008
19	38872000	1	HANDLE
20	23117000	1	ELECTRIC OVEN MOTOR 180W 230V
21	24646200	1	OVEN FAN Ø180
22	24044000	1	TOP ELEMENT 4,5kW 230V FOR OVEN
23	25185100	1	TERMINAL KIT 400 V3N~
24	24685100	4	FOOT 2 - h125/175 - Models from 1/2014
25	38857000	1	FUME DISCHARGE GRID, l=540
26	31839300	1	FONDO CAMERA FORNO 608 x 462 mm