



Position of item	Code	Nr. of pieces	Description
1	35037400	4	HEATING PLATE 300X300 3.5 kW 230V
2	31320000	3	TOP ELEMENT 0.99 kW 230V FE 7/900-K-
3	31320400	3	BOTTOM ELEMENT 1.5 kW 230V FE 7/900-K-
4	35301400	1	THREE-PHASE SAFETY THERMOSTAT (360° C)
5	31802500	2	OVEN HINGE ROLLER HOLDER - Models from 9/2008
6	31802100	1	OVEN DOOR RIGHT HINGE - Models from 1/2000
7	31802000	1	OVEN DOOR LEFT HINGE - Models from 1/2000
8	30064900	1	THREE-PHASE WORKING THERMOSTAT (270° C)
9	22049800	1	4 POSITION SWITCH
10	22050300	1	FOUR-POLE FASTON SWITCH
11	22049900	4	ELECTRIC PLATE SWITCH
12	30169000	1	ORANGE BULB 230V Ø13mm T150°
13	30169100	1	GREEN BULB 230V Ø13mm T150°
14	30169600	2	FIXING CROWN Ø13 FOR INDICATOR LIGHTS
15	30169200	1	ORANGE LIGHT LENS Ø13mm
16	30169300	1	GREEN LIGHT LENS Ø13mm
17	30168000	1	WIRING WITH RESISTOR FOR LIGHTS
18	38952000	4	KNOB BACKING FOR ELECTRIC PLATES
19	38952400	1	KNOB BACKING FOR 2/1 GN ELECTRIC OVENS
20	38952300	1	KNOB BACKING 50°C - 270°C
21	38877500	6	KNOB PA66 PIN 6x4.6 SPACER - Models from 04/2010
22	31856800	1	OVEN GRILL 2/1 GN
23	25185100	1	TERMINAL KIT 400 V3N~
24	24685000	4	FOOT 2 - (out of production see 24685100 ) - Models from 6/2008 - untill 1/2014
25	35857900	2	MATT FLUE PROTECTION GRILL, 400 mm
26	31858600	1	FIBREGLASS OVEN SEAL 2/1 GN - Models from 1/2003 - untill 7/2011