



Position of item	Code	Nr. of pieces	Description
2	22049900	6	ELECTRIC PLATE SWITCH
4	38877600	6	KNOB PA66 PIN 6x4.6 180° SPACER - Models from 1/2010
3	31952500	6	KNOB SILKSCREEN FOR ELECTRIC COOKERS - Models from 1/2000 - untill 12/2009
5	30169100	1	GREEN BULB 230V Ø13mm T150° - Models from 11/2011 - untill
1	22037800	6	ROUND PLATE Ø220 2.6 kW 230V
4	35878300	6	KNOB 6x4,6 - COLOR GRAY - Models from 1/2000 - untill 12/2009
3	38952000	6	KNOB BACKING FOR ELECTRIC PLATES - Models from 1/2010 - untill
5	30168800	6	GREEN LIGHT 230V Ø10 MM T150 - Models from 1/2000 - untill 10/2011
6	30169300	1	GREEN LIGHT LENS Ø13mm - Models from 11/2011 - untill
9	30684100	4	FOOT FOR STAND-ALONE EQUIPMENT
8	25185100	1	TERMINAL KIT 400 V3N~
7	30169600	1	FIXING CROWN Ø13 FOR INDICATOR LIGHTS - Models from 11/2011 - untill