

No	Part Code	Description	Qty.
1	20101060038	Oven Cover	1
2	20101030065	Wave guide (ASSY)	1
3	916040001	Gear motor	1
4	905990002	Magnetron	1
5	905040001	Contactora	1
6	905030001	Contactora base	3
7	20101060036	Inner rear plate,top	1
8	905020001	Hi-limit switch	1
9	20101060037	Rear plate	1
10	20101060046	Exhaust channel	1
11	20101060044	Cooling tunnel	1
12	905140009	Cable Gland	1
13	905060026	Blower Motor	1
14	909010078	Motor blade	1
15	905100001	Capacitor	1
16	905990062	Silicon Stack	1
17	905030004	Heat sink	3
18	905030003	Solid State Relay	3
19	906010067	Heating elements 240V	1
20	905080001	H-V Transformer	1
21	905080003	Frequency converter	1
22	20101060027	Exhaust tube	1
23	20101030009	Hinge, right	1
24	20101060030	Micro switch ASSY	1
25	909010002	Adjustable leg	4
26	905130024	USB Port	1
27	30101060043	Slide guide	1
28	905990040	Cooling fan	1
29	20101060047	Air filter	1
30	905020007	Button switch	1
31	916040002	Filter	2
32	904010024	Mica Plate	1
33	20101060005	Front panel,BTM	1
34	20101060039	Door ASSY.	1
35	20101060026	Inner chamber	1
36	915040009	Die-cast flame	1
37	905160011	Touch Screen Controller	1
38	20101030008	Hinge, left	1
39	905990048	Filter	1
40	905110013	Fuse base	1
41	905020013	Micro switch	3
42	905070016	Temperature Probe	1
43	905990008	Terminal block	1
44	905990005	Fuse	1
45	20101060035	Cover support	1
46	905090005	Power switch	1
47	905030002	Relay	3
48	905990006	Varistor	1
49	905020005	Hi-limit switch	1

