

<u>Code</u>

WSE2S

WSE3S





DRAWER WARMER

CONTENTS

Α	GENERAL INFORMATION	Page	2
A1	PRODUCT DESCRIPTION	Page	3
A2	TECHNICAL INFORMATION	Page	3
A3	TRANSPORTATION	Page	4
A4	UNPACKING	Page	4
В	INSTALLATION	Page	4
С	SAFETY INSTRUCTIONS	Page	5
D	OPERATION	Page	6
E	CLEANING & MAINTENANCE	Page	8
F	TROUBLESHOOTING	Page	9
G	SPARE PART LIST- EXPLODING DRAWING	Page	10
Н	ELECTRIC CIRCUIT SCHEMA	Page	18

A GENERAL INFORMATION

Before installing the appliance, read operation and maintenance instructions carefully. Wrong installation and part changing may damage the product or may cause injury on people. These are not in our company's responsibility to damage the appliance intentionally, negligence, detriments because of disobeying instructions and regulations, wrong connections. Unauthorized intervention to appliance invalidates the warranty.

- 1. This instruction manual should be kept in a safe place for future reference.
- 2. Installation should be made in accordance with ordinances and security rules of that country by a qualified service personnel.
- 3. This appliance has to be used by trained person.
- 4. Please turn off the appliance immediately in the event of malfunction or failure. The appliance should be repaired only by authorized service personnel. Please demand original spare part.

A1 PRODUCT DESCRIPTION

*The Professional Drawer warmer,that provides high efficiency has been designed to be used in industrial kitchens.

Product Code	Dimensions (mm)	Weight (kg)	Packaging Dimensions (mm)
WSE2S	715X568X496	73	775X576X514
WSE3S	715X568X745	106	775X576X764

A2 TECHNICAL INFORMATION

Product Code	Model	Capacity	Power (KW)	Operating Voltage (V)	Cable (mm²)	Insurance selection (A)
WSE2S	Two drawer heating unit	GN 1/1 2 Adet	3,4	220	3x2,5	16
WSE3S	Three drawer heating unit	GN 1/1 3 Adet	5,1	220	3x4	23

A3 TRANSPORTATION

*This appliance can not be moved by hand from area to area. It must be moved on pallet with forklift truck.

A4 UNPACKING

*Please unpack the package according to the security codes and ordinances of current country and get rid from the pack.Parts which contacts with food are produced by stainless steel.All plastic parts are marked by material's symbol.

*Please check that all the parts of appliance had come completely and if they are damaged or not during the shipping.

B INSTALLATION

*Please place the product to straight and sturdy ground, please take necessary steps against possibility of overturn.

*Technician who will serve for installation and service for the appliance must be professional on this subject and must have installation and service licenses by the company.

*Connection to Electric Power Supply must be done by authorized person.

*Please be sure that the voltage connected to appliance must be equal with the voltage which is on appliance's label.

This appliance must be connected to an earthed outlet in accordance with safety rules and standards.

*Appliance's earthing must be connected to earthing line on panel which is nearest to electric installation.

*Connection to the main fuse and leak current fuse must be done in accordance with the current regulations.

C SAFETY INSTRUCTIONS



*Do not use the appliance in insufficient lighted place.



*Do not touch the moving attachments while the appliance operates.



*Do not install the appliance in the presence of flammable or explosive materials.



*Do not operate the appliance when the machine is empty.



*Do not load so less or more than appliance's capacity.



*Do not attempt to use the appliance without suitable protective equipments.



*Because of any reason if there is a fire or flame flare where the appliance is used,turn off all gas valves and electric contactor switch quickly and use fire extinguisher .Never use water to extinguish the fire.



*All the damages because of not having earthing connection will not be on warranty.




*Get the necessary cautions against electric danger.



Do not leave the drawer open when moving the Heating Unit. Uncontrolled movement of the drawer can be dangerous. Unplug the plug from the socket.

D OPERATION

*Control Panel;



A : Digital ScreenB : Up Arrow ButtonC : Down Arrow ButtonD : ON/OFF Button

*Operating;

- Plug in the appliance.
- Maximum operating temperature of the appliance is 99°. If it is more than 90°, the polyurethane may damage the body.
- For dry type heating drain the water in the pool through the drainage tap that is under the appliance.
- Press on/off button.
- Inner temperature will be seen after the lights of the indicator is ON.
- If you press set button of the digital thermostat, the temperature that was set before will be seen on the screen.
- Adjust the desired temperature with direction buttons.
- Press set buton again.
- Inner temperature will be seen on the screen again. It means that the adjusted temperature is saved to the memory.
- Keep the drawer of the device as closed as possible to prevent heat loss.
- Unplug the device from the wall outlet when the device is not in use.

E CLEANING & MAINTENANCE

CLEANING AND MAINTENANCE AFTER EVERY USE

- Be sure that the drawer is cold (below 40°C) before cleaning.
- Always turn off the appliance and disconnect from the power supply before cleaning.
- Clean inside and outside of appliance with hot water and then dry.
- Do not use abrasive cleaning chemicals as these can leave harmful residues.
- Do not clean the appliance by spraying water directly,otherwise electric motor may get damaged.

PERIODIC CLEANING AND MAINTENANCE


- Maintenance should be done by qualified person.
- Get the periodic maintenance of the appliance once in every 15 days.
- At the end of each use, remove the tub and clean the appliance.

F TROUBLESHOOTING

	Check if the appliance is plugged in.
THE APPLIANCE DOESN'T OPERATE	2. Check the electrical connections and
	voltage.
	Check the heater resistance and
	thermocouple.
THE APPLIANCE DOESN'T HEAT	2. Fan may have error.In this situation
	inform the service.
	3. If the door has error,or door wick is
	broken,the appliance doesn't heat.
	The appliance can stop due to low
	voltage.In this situation check the
THE APPLIANCE STOPPED	voltage.
	2. If there is a any weight on the device ,
	the device may stop.


- If heating is not done at suitable quality
- If any function of security doesn't work
 - > Do not use the appliance.

^{*}If these problems are still going on, contact with our authorized services.




WSE1S

PRODUCT CODE: WSE1S			
NO	NAME OF THE PRODUCT		
1	CHASSIS		
2	REZISTANCE		
3	FAN MOTOR		
4	1/1 TUB		
5	TELESCOPIC SLIDE		
6	DRAWER HOLDER		
7	VENT HOLDER		
8	DRAWER		
9	CONTROL PANEL		
10	THERMOCOUPLES		
11	STAND		
12	GASKET		



WSE2S


PRODUCT CODE: WSE2S			
NO	NAME OF THE PRODUCT		
1	CHASSIS		
2	REZISTANCE		
3	FAN MOTOR		
4	1/1 TUB		
5	TELESCOPIC SLIDE		
6	DRAWER HOLDER		
7	VENT HOLDER		
8	DRAWER		
9	CONTROL PANEL		
10	THERMOCOUPLES		
11	STAND		
12	GASKET		



WSE3S

PRODUCT CODE: WSE3S			
NO	NAME OF THE PRODUCT		
1	CHASSIS		
2	REZISTANCE		
3	FAN MOTOR		
4	1/1 TUB		
5	TELESCOPIC SLIDE		
6	DRAWER HOLDER		
7	VENT HOLDER		
8	DRAWER		
9	CONTROL PANEL		
10	THERMOCOUPLES		
11	STAND		
12	GASKET		

H ELECTRIC CIRCUIT SCHEMA



R1	M2	M1	TC
Inner temperature resistance 1700 W	Cooling Panel fan 230V.	Air circulation fan 38 KW. 220V.	Probe J type



GGM Gastro International GmbH Weinerpark 16 D-48607 Ochtrup

www.ggmgastro.com info@ggmgastro.com +49 2553 7220 0