

BEHEIZBARE BANKETTWAGEN

Modell Nr.: TGNP1711 & TTWP37H & TTWP37N
TGNP2211 & TTWP31H & TTWP31N
TGNP2811 & TTWP32H & TTWP32N



Bitte lesen Sie diese Anleitung vor der Inbetriebnahme sorgfältig durch, um eine korrekte und sichere Installation und Nutzung zu gewährleisten. Bei Schäden, die durch Nichtbeachtung dieser Anleitung verursacht werden, erlischt in jedem Fall der Garantieanspruch.

Die GGM Gastro GmbH weist darauf hin, dass diese Bedienungsanleitung vor der Inbetriebnahme sorgfältig gelesen und für den späteren Gebrauch aufbewahrt werden

TECHNISCHE DATEN:

MODELL	ABMESSUNGEN (CM)	SPANNUNG (V)	HERTZ	LEISTUNG (W)
TTWP37H	12,5 (H)x38,4x77,4	220-230	50	1075
TTWP31H	12,5 (H)x38,4x99,4	220-230	50	1200
TTWP32H	12,5 (H)x38,4x124,9	220-230	50	1300

Für weitere Informationen möchten wir Sie bitten, unsere Website www.gmgastro.com zu besuchen. Sie können zum Beispiel nach der Artikelnummer suchen.

TRANSPORT UND LAGERUNG:



Achten Sie darauf, dass Sie die Wagen niemals auf den Kopf stellen. Dies könnte das Gerät beschädigen. Während des Transports sollte das Gerät vorsichtig abgestellt werden. Achten Sie darauf, dass es während des Transports nicht zu starken Erschütterungen kommt. Stellen oder lagern Sie dieses Produkt niemals im Freien oder im Außenbereich (auch nicht verpackt). Es sollte in einem gut belüfteten Lager ohne korrosive Gase gelagert werden. Wenn Sie es im Notfall vorübergehend im Freien lagern müssen, sollten Sie Maßnahmen ergreifen, um es vor Regen oder Feuchtigkeit zu schützen.

SICHERHEITSVORKEHRUNGEN UND EINSATZUMGEBUNG:

1. Entfernen Sie das gesamte Verpackungsmaterial und alle Schutzfolien vom Gerät.
2. Dieses Produkt sollte in einem ausgewogenen und gut belüfteten Ort platziert werden und seine linken und rechten Seiten sollten frei von Hindernissen für mehr als 10cm sein. Die Rückseite sollte mehr als 20 cm von Hindernissen (wie z. B. einer Ziegelmauer) entfernt sein.
3. Stellen Sie das Gerät nicht auf einen Teppich, ein Geschirrtuch, ein Tischtuch (Vinyl) oder eine andere Oberfläche, die hohen Temperaturen nicht standhält. Dies könnte eine Brandgefahr darstellen.
4. Vermeiden Sie die Blockierung des Lüftungsgitters.
5. Stellen Sie während des Betriebs keine Gegenstände vor das Gerät, um sicherzustellen, dass es jederzeit bedient werden kann.
6. Vor der Verwendung muss dieses Gerät an eine geerdete Steckdose angeschlossen werden. Prüfen Sie vor der Inbetriebnahme, ob die Steckdose, die Sie verwenden möchten, geerdet ist.
7. Die Versorgungsspannung des Gerätes (230 Volt/50 Hz/1 Ph) muss mit der Spannung des Stromnetzes übereinstimmen.
8. Der Benutzer muss einen geeigneten Netzschalter, eine Sicherung und einen Fehlerstromschutzschalter in der Nähe des Geräts installieren. Achten Sie darauf, dass der Schalter immer leicht zugänglich ist, damit er im Gefahrenfall leicht zu betätigen ist und sofortige Maßnahmen ergriffen werden können.
9. Never put the plug in the socket with wet hands. This is very dangerous.
10. Never plug the power cord into an extension cord or wall outlet to which multiple devices are connected.
11. If the plug does not connect properly to the socket, you are not allowed to connect it.
12. Before usage you should check whether all components are available and whether the appliance is not damaged (please pay extra attention on the wheels and the push handles).
13. Make sure whether all the connections of all the electric elements of the product are firm or not.
14. When you change the power cable, you should select the same model.
15. If you need to (re)connect, repair or maintain the appliance, do not do this by yourself. This is forbidden. This must always be done by a professional electrician.

16. If there are any abnormal phenomenon's during usage, you must turn off the appliance immediately. Please contact your local dealer in case of doubt about the product it's safety. Again, do not repair the appliance by yourself! This should always be done by a technical professional.
17. During operation or cooling down: always keep the appliance out of reach of children. This, mainly to prevent danger and burning injuries.

SAFETY INSTRUCTIONS

DEGREASE:

1. Open the door.
2. Before putting the appliance into operation, clean the inside with warm water, a cloth and a small amount of detergent. Never rinse the appliance under the tap or by use of a water hose / sprayer, this can seriously damage the electrical components. In addition, before putting the appliance into operation, make sure that you have dried it properly.

REGULAR USE:

1. Never use other spare parts than the ones which are from. GGM GASTRO INTERNATIONAL GmbH is not taking any responsibility for damage caused by the use of other (non-related) parts.
2. Do never cover the appliance with foil. This could cause overheating and therefore danger.
3. Make sure you take the time to let the appliance reach the desired temperature.
4. Only place the trolley on straight surfaces. Although the wheels have brakes, the weight of the trolley can tip the trolley if it is not placed on a straight surface.
5. If you want to leave the appliance and its surroundings, the appliance must be switched off and the plug must be removed from the socket. Make sure the switch is turned OFF before you cut the electricity from the socket, this is to prevent short circuit or danger.
6. Never leave the surroundings of the appliance during operation.
7. Never move the appliance during operation (when it is connected to the power supply).
8. Never touch the appliance (besides the control panel, the brakes and the push handles) during operation.
9. When disconnecting the device from the power, never pull from the cord, only the plug.

PRODUCT STRUCTURE/PARTS

1. push handles
2. cord / plug
3. s/s bottom plate
4. wheels
5. cord and plug (extendable length is 4 meter)
6. door (fan and motor)

*If the motor or fan is defective, please contact your local dealer. Do not tinker with the door independently. Once the motor or fan has been determined to be faulty, it is advised to replace the complete door.

How do you remove the door?

* If you want to use the trolley unheated and/or unclosed, you can do this by carefully removing the door from the trolley.

Do this as follows:

1. Open the door.
2. Hold the door firmly with 2 hands and lift it up gently (the door is now free from the hinges).
3. Move the door carefully and always keep it indoors (and dry).
4. If you want to replace the door on the trolley, you are requested not to do this alone, but with the help of a second person. This will make it easier for you and therefore reduce the chance of damage. In case you do not have help and you do decide to do it by yourself, always make sure you secure the four wheels with the brakes.

CONTROL PANEL

Switch: ON/OFF.

'**set**': Sets the temperature. Press '**set**' once and the display will show the maximum temperature of 90 Degrees Celsius. Then set the desired temperature using '□' or '□' and press '**set**' again to confirm. The display now shows the current temperature.

ERROR MESSAGES

PFA No communication with thermostat sensor.(Sensor and/or cable broken or not connected.)

PSC Thermostat probe or connection line short-circuited.

----- Temperature value is higher than the scale.

_____ Temperature value is lower than the scale.

CLEANING AND MAINTENANCE:

Step 1: After usage, the device must first be switched OFF, after which you must remove the plug from the socket. Always do this in the order described to prevent short circuit or other possible dangers.

Step 2: Make sure the appliance has cooled down.

Step 3: Clean the parts and the device with warm water, a wet cloth and a small amount of cleaning-detergent and then dry it thoroughly. Do not use benzine, thinner, scouring brush or polishing powder to clean the device.

• Pay attention!

- Do not rinse the device with water (don't wash it by using the tap or spray). This could cause damage to the device and could therefore lead to dangerous situations.
- Never clean the device with a stainless steel brush. This causes scratches and damages the device.
- Use a vacuum cleaner to (gently) remove dirt and debris from the air-ventilation-grille.
- Always store the trolley inside and keep it dry.
- Before maintaining the appliance, always make sure you have removed the plug from the socket.

If the appliance does not work or is damaged, check the following:

1. Whether the plug is in the socket;
 2. Whether the plug and/or the cord is damaged;
 3. Whether the microswitch works.
- if another problem occurs, contact your local dealer or authorized service technician.



According to Waste of Electrical and Electronic Equipment (WEEE) directive, WEEE should be separately collected and treated. If at any time in future you need to dispose of this product please do NOT dispose of this product with household waste. Please send this product to WEEE collecting points where available.